


FTTH Distribution Box



The distribution box is made of anti-aging ABS plastic material, resistant against mechanical effects.

The cover opens horizontally and is equipped with lock and latch.

The metal plate with adaptor connection swings effortlessly for easy installation.

Box is fitted with gaskets to protect the optical fibres inside against moisture, dust, wind and the entrance of insects.

Installation is easy, no special tools are required.

The distribution box is suitable for wall and pole installation, the triangle keylock according to industrial standards.

The box may be fitted with SC / APC or FC / PC simplex or duplex adaptors, alternatively with LC quad adaptors, depending on demand.

Capacity: 24 fibres with standard adaptors
48 fibres with LC quad adaptors

Dimensions: 420 x 260 x 110 mm

Installation Instruction




1. Strip cable: L = 0,9m



2. Fix incoming and outgoing cables




3. Splice the optical fibres




4. Fix the optical fibres to the tray




5. Using connector or splitter



6. Duplex connection to subscriber




7. Fix the subscriber cable



8. Finished

Pole installation



Insert an A200 stainless steel band through the base of the box.



Contact Details

SENTAL Export GmbH
Ziethenstrasse 18
D-22041 Hamburg

+49 40 656 92 01
+49 40 656 56 09
info@sental.de