Tools

Consumable and tools

2.5mm & 1.25mm One-click Ferrule Mate Cleaner

Description

Our company provides high quality One-click Ferrule Mate Cleaner for $\varphi 2.5 \text{mm} \& \varphi 1.25 \text{mm}$ optical ferrules. As a high precision components, even a little contaminants on the optical ferrule can affect the performance of the whole optical transmission system. If an optical ferrule is polluted, it is hard to make it clean again in ordinary ways for the high requirements of the cleaning equipment and the little space the ferrule left for cleaning. With the One-click Ferrule Mate Cleaner, all the problems can be solved easily. The cleaner is composed with special cleaning reel, extendable nuzzle and guide cap of specified size. These make the cleaner meet rigorous requirements of the cleaning solution. The One-click Ferrule Mate Cleaner is absolutely your good partner in optical cleaning solution.

- \bullet Suitable for optical connector or port with $\phi 2.5 mm/\phi 1.25 mm$ ferrule, such SC, FC, ST and etc.
- · One click cleaning system, easy, fast and high efficiency
- · More than 800 cleaning cycles
- Effective with variety of contaminants Composed with dust cap and guide cap for unmated ferrules
- Complied with EU/95/2002/EC Directive(RoHS)



Mate Cleaner

Specification

φ2.5mm one-click t	ferrule mate cleaner
Dimension (mm)	80*13*13(standard)/115*13*13(nozzle extended)
Weight (kg)	0.1
Connector type	All φ2.5mm connectors , such as SC, FC, ST
Cleaning cycles	800 cycles
φ1.25mm one-cli	ck ferrule mate cleaner
Dimension (mm)	80*13*13(standard)/115*13*13(nozzle extended)
Weight (kg)	0.1
Connector type	All φ1.25mm connectors , such as LC, MU, E2000
Cleaning cycles	500 cycles